


ILS or LOC RWY 32
SOUTHERN WISCONSIN RGNI (JVL)

MISSED APPROACH: Climb to 1700 then climbing left turn to 3100 direct TIRRO and hold.

UNICOM

1700	3100	TIRRO				
CATEGORY	A		B		C	D
S-LS 32	1006- $\frac{1}{2}$ 200 (200- $\frac{1}{2}$)					
S-LOC 32	1200- $\frac{1}{2}$ 394 (400- $\frac{1}{2}$)			1200- $\frac{5}{8}$ 394 (400- $\frac{5}{8}$)		
CIRCLING	1260-1 452 (500-1)	1320-1 512 (600-1)	1420-1 $\frac{3}{4}$ 612 (700-1 $\frac{3}{4}$)	1460-2 652 (700-2)		