

VOR/DME SBJ
112.9
Chan 76

APP CRS
171°

Rwy Idg
TDZE
Apt Elev
128

N/A
N/A
128

VOR-A
PRINCETON (39N)

DME required.


▼

NA

Circling Rwy 28 NA at night. Use Trenton altimeter setting; when not received, use Somerville altimeter setting.

MISSED APPROACH: Climbing left turn to 2300 direct SBJ VOR/DME and hold.

TTN ASOS 126.775	NEW YORK APP CON 132.8 379.9	UNICOM 122.725 (CTAF)	123.05 0
---------------------	---------------------------------	--------------------------	----------



One Minute Holding Pattern

SBJ VOR/DME

DFRTZ INT SBJ 7.2

2300 SBJ

6000 2300

351° 171°

171°

1800

7.2 NM 4.4 NM

MIRL Rwy 10-28 0

REIL Rwy 10 0

FAF to MAP 4.4 NM

Knots	60	90	120	150	180
Min:Sec	4:24	2:56	2:12	1:46	1:28

CATEGORY	A	B	C	D
CIRCLING	1040-1¼	912 (1000-1¼)	NA	